


Перед настройкой вам необходимо позвонить в службу тех. поддержки Вермонт-ИТ и сообщить, что вы будете настраивать роутер (понадобится сбросить привязку по MAC-адресу). После этого необходимо вставить кабель, который идет в комплекте с роутером в разъем «1» роутера, а другой конец вставить в сетевой разъем компьютера. После этого интернет-кабель нужно вставить в разъем «Internet» роутера.

1. Откройте любой браузер (например, Internet Explorer) и перейдите на страницу 192.168.0.1.



2. Для входа в панель управления введите логин admin, поле «Password» оставьте пустым и нажмите на кнопку «Вход».

A screenshot of a web page titled "LOGIN" with a green header. Below the header, the text "Login to the router" is displayed. There are two input fields: "Username:" with the value "admin" and "Password:" which is empty. To the right of the password field is a button labeled "Login".

3. Выберите пункт «Manual Internet Connection Setup».

A screenshot of a web page titled "MANUAL INTERNET CONNECTION OPTIONS" with a dark header. Below the header, the text reads: "If you would like to configure the Internet settings of your new D-Link Router manually, then click on the button below." Below this text is a button labeled "Manual Internet Connection Setup" which is highlighted with a red rectangular border.

4. В меню «Internet connection type» укажите «Static IP».

A screenshot of a web page titled "INTERNET CONNECTION TYPE" with a dark header. Below the header, the text reads: "Choose the mode to be used by the router to connect to the Internet." There is a label "My Internet Connection is:" followed by a dropdown menu. The dropdown menu is open, showing a list of options: "Dynamic IP (DHCP)" (highlighted in blue), "Static IP", "PPPoE (Username / Password)", "PPTP (Username / Password)", "L2TP (Username / Password)", "Russia PPPoE (Dual Access)", and "Russia PPTP (Dual Access)". Below the dropdown menu, there is a section titled "DYNAMIC IP (DHCP) INT" and some partially visible text about IP address information and ISP.

В появившиеся поля введите сетевые реквизиты в соответствии с договором. Отдельно проверьте DNS сервера. Если в договоре они прописаны не так, как на картинке, то

следует взять адреса с картинки. В поле «MAC Address» следует оставить значение, которое выставлено по умолчанию.

STATIC IP ADDRESS INTERNET CONNECTION TYPE

Enter the static address information provided by your Internet Service Provider (ISP).

IP Address:

10.10.254.254

(assigned by your ISP)

Subnet Mask:

255.255.255.0

ISP Gateway Address:

10.10.254.1

Primary DNS Address:

10.100.100.6

Secondary DNS Address:

77.91.193.205

(Optional)

MTU:

1500

MAC Address:

FC

-

75

-

16

-

9C

-

B7

-

2F

(Optional)

Duplicate MAC address from your current PC

5. Нажмите на кнопку «Save settings» внизу окна.